



OUR RECOMMENDATIONS

PERFECT INSTALLATION HEIGHTS

Everyone is different, which is why everyone will have a different idea about what the perfect installation height is. If nothing is said to the contrary, plumbers will install bathroom elements at the heights stipulated in the standard.

- 1 WC**
Height top edge WC ceramic (without WC seat):
41 cm – 42 cm
- 2 WASHBASIN**
Height top edge washbasin ceramic: 85 cm – 90 cm
- 3 MIRROR OR MIRROR CABINET**
Height bottom edge: 100 cm – 125cm
Height top edge: 200 cm – 220 cm
Height eye area: The center of the mirror surface.
This depends whether people with a lower eye level also want to comfortably use the mirror.
- 4 CLOTHES HOOK**
Between 110 cm and 120 cm